Locust




설치

```
$ pip install locust
```

준비

```
//locustfile.py
from locust import HttpUser, task
class ServerTest(HttpUser):
    @task
    def api_test(self):
        self.client.get("/")
```


https://argos-movie.netlify.app/home



실행


```
$ locust
$ locust -f {파일명}.py
[2022-12-30 11:59:47,448] /locust.main: Starting web interface at
http://0.0.0.0:8089 (accepting connections from all network interfaces)
[2022-12-30 11:59:47,454] /locust.main: Starting Locust 2.14.0
```

테스트





서버



```
/locust.main: Shutting down (exit code 1)
Type
    Name
                            # regs
                                 # fails ¦
                                        Avg Min Max Med | reg/s failures/s
    GET
    /home/
                            25713 360(1.40%) ¦
                                        406 73 30005 110 | 537.69
                                                               7.53
     Aggregated
                            25713 360(1.40%) |
                                        406
                                          73 30005 110 | 537.69
                                                               7.53
Response time percentiles (approximated)
Type
    Name
                                50%
                                   66%
                                       75%
                                          80%
                                             90% 95% 98% 99% 99.9% 99.99% 100% # regs
210 370 16000 30000 30000 30000 25713
GET
                                110
                                          140
                                              170
    /home/
110
                                       130 140 170 210 370 16000 30000 30000 30000 25713
    Aggregated
                                   120
Error report
# occurrences
         Error
                ._____
230
         GET /home/: ConnectionResetError(54, 'Connection reset by peer')
         GET /home/: ReadTimeout(ReadTimeoutError("HTTPSConnectionPool(host='argos-movie.netlify.app', port=443): Read timed out. (read
timeout=None)"))
         GET /home/: RemoteDisconnected('Remote end closed connection without response')
38
                ______
```